

SHIFT CASE by INO VR

# QUICK-START

## GUIDE

VIVE XR ELITE VERSION

2-MINUTE SETUP

1

**STEP 1**

Open your case by activating the locking system.

2

**STEP 2**

Once the case is open, remove the wireless keyboard from its slot, then the headset and controllers from the foam.

3

**STEP 3**

Connect the power supply to an electrical socket.



4

**STEP 4**

Make sure the power supply is in the "ON" position.

5

**STEP 5**

Press the power button on the front of the case (the button lights up when the computer starts).

6

**STEP 6**

Make sure that the router (included as an option) is plugged in and that the "ON" position is engaged.

**YOUR CASE IS READY, TIME TO START  
YOUR HEADSET**

**FOR WIRED USE****1****STEP 1**

Make sure that the Vive Business Streaming application is installed and running on your computer.

**2****STEP 2**

Start your headset by pressing the button on the front of the headset.


**3****STEP 3**

Connect the Vive Business Streaming cable to your headset and computer.

**4****STEP 4**

Put on your headset and start your controllers.

5

**STEP 5**

Go now to the Vive Business Streaming application in the headset library.

**YOU ARE NOW READY TO LAUNCH  
YOUR COMPUTER APP 😊**

**FOR WIRELESS USE****1****STEP 1**

Make sure that the Vive Business Streaming application is installed and running on your computer.

**2****STEP 2**

Start your headset by pressing the button on the front of the headset.


**3****STEP 3**

Put on your headset and start your controllers.

**4****STEP 4**

Make sure the headset is connected to the same WiFi network as the computer (and the router, if applicable).

5



## STEP 5

Now go to the vive business streaming application in the headset library and select your computer

**YOU ARE NOW READY TO LAUNCH  
YOUR COMPUTER APP 😊**